

# QUICK START

2740-200200v1.2

## CONNECT YOUR NEW RSP-Z2

### What You Need to Get Started:

- ✔ Computer with a web browser
- ✔ CAT 5e or higher Ethernet cable (qty: 1)
- ✔ Network settings you want to assign to the RSP-Z2 so it can connect to the network (LAN) where it is located. *E.g., IP address, subnet mask, gateway, DNS server(s)*

The RSP-Z2 has a static IP address.  
Follow these steps to begin configuration:

- 1 Avoid potential network conflicts. In your computer's network settings options, set your machine to a static IP address of 192.168.1.199 and a subnet mask of 255.255.255.0 to allow you to browse to the RSP-Z2 at its default IP address.
- 2 Using an Ethernet cable, connect the RSP-Z2 directly to the Ethernet port on your computer.

For help, go to  
[support.jps.com](https://support.jps.com)



- 3 Plug in the RSP-Z2's power supply and turn it on. Wait approx 30 seconds until the front panel LEDs stop flashing.
- 4 Using a desktop web browser, go to 192.168.1.200 and log in:  
**Default Username: su**  
**Default Password: su**
- 5 In the top banner, select Network from the Settings menu. Enter the IP address, subnet mask, gateway, and DNS server(s) you want this RSP-Z2 to use on your network. (Assigning gateway and DNS is recommended, and necessary for many applications.)
- 6 Once you are ready, click Save. The unit will reboot and integrate the new settings so you can put the RSP-Z2 on your network.
- 7 Disconnect the Ethernet cable from your computer and plug it into your network. The Ethernet cable now connects the RSP-Z2 to your network (via switch, etc.).
- 8 Reconfigure/change your computer's network settings so it can connect to the same network as the RSP-Z2.
- 9 Browse to the RSP-Z2's new IP address and log in.
- 10 JPS periodically releases new Z-Series software. Download the most recent software at [support.jps.com](http://support.jps.com)



Learn more about the RSP-Z2. The Product Tour and the Field Setup Guide (both in the Help menu) briefly introduce many key concepts and capabilities.